



Using Integrator

Speaker: Nelson Chang

Directed by Prof. Tian-Sheuan Chang

April, 2004, NCTU

Outline



- ☐ Downloading program to Integrator
- ☐ Turning-off Integrator

Downloading Program to the Integrator



- ☐ Connect Multi-ICE to the JTAG connector on CM
- ☐ Connect Multi-ICE to PC's parallel port
- ☐ Connect Multi-ICE's power
- ☐ Power on the Integrator system
- ☐ Start “Multi-ICE server” program
 - Press Auto-Configure
- ☐ Start AXD
 - Options → Configure Target
 - Select MultiICE as debug target
 - Load the image and run

Turning-off the Integrator

- ☐ Close AXD
- ☐ Power down the Integrator system
- ☐ Close “Multi-ICE Server” program
- ☐ Disconnect Multi-ICE from PC
- ☐ Disconnect Multi-ICE from Integrator CM
- ☐ Disconnect the power line of the Integrator